

IGLOO YUKON 70-QUART COOLER

Quick-use guide | Model 50906 | Costco item 1872196

PRODUCT AT A GLANCE

- 70-quart insulated cooler; holds up to 112 cans (manufacturer-stated capacity).
- Foam-insulated body and lid, removable interior wire basket, four lid cup holders, bottle opener, tie-down points, and anti-skid base pads.
- Lid includes a self-stopping hinge, rubber latches, and a stainless steel lock plate (padlock not included).

BEFORE FIRST USE

- Inspect the cooler, latches, lid seal, drain plug, and handles for damage.
- Wash or wipe the inside, lid, and basket with water and mild detergent; rinse thoroughly and dry.
- Make sure the threaded drain plug is fully closed before adding ice or water.

USING THE COOLER

- For better cooling, chill food and drinks beforehand and pre-chill the cooler when practical.
- Add ice or ice packs and your chilled items. Use the removable wire basket to keep selected items above loose ice or meltwater.
- Close the lid and fasten the latches. Limit how often the lid is opened to help retain cold temperatures.
- Use the built-in handles for carrying; use the tie-down points when securing the cooler for transport.
- For draining, place the cooler where water can flow safely, carefully unscrew the drain plug, then refit and tighten it after emptying. The threaded outlet can accept a suitable hose connection.

SAFETY & CARE

- Keep perishable food at a food-safe temperature; a cooler does not actively refrigerate. Check with a food thermometer when needed.
- Do not allow children to climb or become enclosed inside the cooler. Keep fingers clear of the lid and latches.
- After every use, empty all contents and meltwater. Clean with mild detergent; for tougher stains, try diluted baking soda and water.
- Rinse away cleaners and let the interior dry completely before storage to reduce odors and stains.

QUICK TROUBLESHOOTING

- Ice melts quickly: start with colder contents, increase ice, reduce lid openings, and confirm the lid is fully latched.
- Water leaks at drain: check that the plug is correctly seated, tightened, and free of debris or damage.
- Odor or staining: empty promptly, clean and rinse thoroughly, then air-dry with the lid open.

IGLOO SUPPORT

1-800-273-7024 | support@igloocoolers.zendesk.com | www.igloocoolers.com/pages/contact-us

Unofficial quick-use guide prepared from available product information; not the manufacturer's original manual.